



# QwikDuct HDPE CUSTOM TEMPLATES




**PROVIDE SAFER & FASTER  
INSTALLATION PLUS ALLOW CLOSING  
TRENCH QUICKER TO REDUCE CHANCE  
OF DANGEROUS AND COSTLY SOIL  
OR WATERPROBLEMS.**

- WHEN ASSEMBLING ABOVE THE TRENCH:**
1. Install Conduits into Templates & Rebar if Required
  2. Lower Assemblies into Trench
  3. Insert Stake Down Rods into Angled Slots
  4. Drive Stake Down Rods into Trench Walls from Above
  5. Backfill with Concrete, Slurry, Sand or Gravel etc.

- WHEN ORDERING CUSTOMER MUST SPECIFY:**
1. Material Thickness ( $\frac{3}{8}$ " ,  $\frac{1}{2}$ " ,  $\frac{3}{4}$ " ) and Load Rating Required ( $\frac{1}{2}$ " and  $\frac{3}{4}$ " are special order materials)
  2. Size & Location of Rebar Holes
  3. Spacing Between Conduit Openings
  4. Rebar Stake Down Slots Required?
  5. Diameter of Conduits
  6. Footage Between Templates
  7. Size & Location of Concrete Flow Thru Holes

SEE WEBSITE  
VIDEO **IP1-3**



Workers insert rods thru angled slots and drive into trench walls from above to prevent floating during concrete pour

- Concrete flow thru holes. *Note: specify size and location.*
- Conduit Holes Larger than Conduit OD (see IP3)
- Rebar holes available at locations specified



*3/4" HDPE for Greater Strength to Accommodate Wheels Assemblies*

**2" Diameter Wheels are Standard  
Larger Size Diameters Available  
Upon Request**

*Roll assembled conduit into caissons under obstructions.*



*This Template is Shown as Sample Only*

**Customer must specify larger diameter holes to enable feeding bell ends of conduit from either direction.**



**PATENT PENDING  
PATENTED**



**LABELS APPLY TO PRODUCTS ONLY WHERE SHOWN ABOVE**

730 Pratt Boulevard • Elk Grove Village, IL 60007  
 P: (847) 593-8595 • F: (847) 593-8629 • Toll-free (800) 233-8595  
 E: info@spproducts.com • www.spproducts.com

**IP2**