



QwikDuct HDPE

CUSTOM TEMPLATES




PROVIDE SAFER & FASTER INSTALLATION PLUS ALLOW CLOSING TRENCH QUICKER TO REDUCE CHANGE OF DANGEROUS AND COSTLY SOIL OR WATERPROBLEMS.

- WHEN ASSEMBLING ABOVE THE TRENCH:**
1. Install Conduits into Templates & Rebar if Required
 2. Lower Assemblies into Trench
 3. Insert Stake Down Rods into Angled Slots
 4. Drive Stake Down Rods into Trench Walls from Above
 5. Backfill with Concrete, Slurry, Sand or Gravel etc.

- WHEN ORDERING CUSTOMER MUST SPECIFY:**
1. Material Thickness ($\frac{3}{8}$ " , $\frac{1}{2}$ " , $\frac{3}{4}$ ") and Load Rating Required ($\frac{1}{2}$ " and $\frac{3}{4}$ " are special order materials)
 2. Size & Location of Rebar Holes
 3. Spacing Between Conduit Openings
 4. Rebar Stake Down Slots Required?
 5. Diameter of Conduits
 6. Footage Between Templates
 7. Size & Location of Concrete Flow Thru Holes


SEE WEBSITE VIDEO **IP1-2**



This Template is Shown as Sample Only

Workers insert rods thru angled slots and drive into trench walls from above to prevent floating during concrete pour

- Concrete flow thru holes. *Note: specify size and location.*
- Conduit Holes Larger than Conduit OD (see IP3)
- Rebar holes available at locations specified



3/4" HDPE for Greater Strength to Accommodate Wheels Assemblies

2" Diameter Wheels are Standard
Larger Size Diameters Available Upon Request

Roll assembled conduit into caissons under obstructions.

Customer must specify larger diameter holes to enable feeding bell ends of conduit from either direction.



PATENT PENDING
PATENTED



LABELS APPLY TO PRODUCTS ONLY WHERE SHOWN ABOVE

730 Pratt Boulevard • Elk Grove Village, IL 60007
P: (847) 593-8595 • F: (847) 593-8629 • Toll-free (800) 233-8595
E: info@spproducts.com • www.spproducts.com

IP2