



QwikDuct HDPE CUSTOM TEMPLATES




**PROVIDE SAFER & FASTER
INSTALLATION PLUS ALLOW CLOSING
TRENCH QUICKER TO REDUCE CHANCE
OF DANGEROUS AND COSTLY SOIL
OR WATERPROBLEMS.**

- WHEN ASSEMBLING ABOVE THE TRENCH:**
1. Install Conduits into Templates & Rebar if Required
 2. Lower Assemblies into Trench
 3. Insert Stake Down Rods into Angled Slots
 4. Drive Stake Down Rods into Trench Walls from Above
 5. Backfill with Concrete, Slurry, Sand or Gravel etc.

- WHEN ORDERING CUSTOMER MUST SPECIFY:**
1. Material Thickness ($\frac{3}{8}$ " , $\frac{1}{2}$ " , $\frac{3}{4}$ ") and Load Rating Required ($\frac{1}{2}$ " and $\frac{3}{4}$ " are special order materials)
 2. Size & Location of Rebar Holes
 3. Spacing Between Conduit Openings
 4. Rebar Stake Down Slots Required?
 5. Diameter of Conduits
 6. Footage Between Templates
 7. Size & Location of Concrete Flow Thru Holes

SEE WEBSITE
VIDEO **IP1-2**



While above trench workers insert rods thru slots and drive into trench walls to prevent floating during concrete pour

- Concrete flow thru holes. *Note: specify size and location.*
- Conduit Holes Larger than Conduit OD (see IP3A)
- Rebar holes available at locations specified



This Template is Shown as Sample Only

3/4" HDPE for Greater Strength to Accommodate Wheels Assemblies

**2" Diameter Wheels are Standard
Larger Size Diameters Available Upon Request**

Roll assembled conduit into caissons under obstructions.

Customer must specify larger diameter holes to enable feeding bell ends of conduit from either direction.



PATENTED

LABELS APPLY TO PRODUCTS ONLY WHERE SHOWN ABOVE



730 Pratt Boulevard • Elk Grove Village, IL 60007
 P: (847) 593-8595 • F: (847) 593-8629 • Toll-free (800) 233-8595
 E: info@spproducts.com • www.spproducts.com

IP2